




**American
International**
Car Stereo Installation Kits & Accessories



SBK926 Mounting Kit



www.aampglobal.com www.aius.net

2500 East Francis Street Ontario, CA 91761, U.S.A.

Sales: (800) 477-2267

Intl: (727) 572-9255

Support: 888-228-5560

VEHICLE APPLICATIONS

Subaru

2009-13 FORESTER

2008-11 IMPREZA

2008-14 IMPREZA WRX

DASH DISASSEMBLY


1. Open the Passenger door and remove the end cover exposing the (1) Phillips screw securing the right end of the Vent/Trim panel to the right end side of the dash.
2. Remove the (1) Phillips screw securing the right end of the Vent/Trim panel to the side of the dash, and carefully starting with the Vent end, pry the trim panel forward working toward the radio. It is not necessary to remove the trim completely, just unclip to the left side of the radio and rest out of the way.
3. Carefully unclip and remove the Vent/radio trim bezel.
4. Remove the (4) Phillips screws securing the radio to the sub-dash, pull the radio forward, disconnect all attached harnesses and antenna lead and remove radio.

KIT ASSEMBLY INSTRUCTIONS

Single ISO Mount Applications

1. Insert left and right mounting brackets to rear of kit as shown in Figure A and secure to rear of kit fascia using (4) small phillips screws included in kit.
2. Insert pocket into lower section of the brackets and snap into rear pocket support tabs.
3. Insert ISO mountable radio between ISO mount brackets and loosely attach to sides of radio using screws provided with radio when possible or screws supplied with kit.
4. Slide radio forward or backward for desired look and tighten screws.

Fig A



Double DIN Mount Applications

1. Insert IMB-926 L&R into rear of kit & attach using 4 screws supplied w/kit (See Fig B for bracket tab removal).
2. Insert ISO mountable radio between ISO mount brackets and loosely attach to sides of radio using screws provided with radio when possible or hardware included with kit.
3. Slide radio component forward or backward for desired look and tighten screws.
4. Attach a rear support bracket to the rear of the new radio and adjust as necessary to support the weight of the radio.

Fig B

